


SW80 Series Contactor

Original Albright



LT#	Model Number	Voltage	Current
A.A.01.0312A1	SW80-58	12V	125A
B.B.01.1124A2	SW80-65	24V	125A
A.A.01.0336A1	SW80-8	36V	125A
A.A.01.0348A1	SW80B-156	48V	125A
A.A.01.0380A2	SW80B-2149	80V	125A

OEM Part



Contactor Kit for SW80
A.A.21.0380G1

LT#	Voltage	Current
A.A.01.0312G1	12V	100A
B.B.01.1124G1	24V	100A
A.A.01.0336G1	36V	100A
A.A.01.0348G1	48V	100A
A.A.01.0360G1	60V	100A
A.A.01.0372G1	72V	100A
A.A.01.0380G1	80V	100A

SW180 Series Contactor

Original Albright



LT#	Model Number	Voltage	Current
B.B.01.1224A1	SW180B-751	24V	200A
A.A.01.0436A1	SW180-6	36V	200A
A.A.01.0448A1	SW180B-108	48V	200A
A.A.01.0480A1	SW180B-14	72/80V	200A

SW180 Series Contactor

OEM Part



Contactor Kit for SW180
A.A.21.0480G1

LT#	Voltage	Current
B.B.01.1212G1	12V	200A
B.B.01.1224G1	24V	200A
A.A.01.0436G1	36V	200A
A.A.01.0448G1	48V	200A
A.A.01.0480G1	80V	200A

SW181 Series Contactor

Original Albright



LT#	Model Number	Voltage	Current
A.A.01.0624A1	SW181B-241T	24V	200A
A.A.01.0648A1	SW181B-245T	48V	200A
A.A.01.0680A1	SW181B-248T	80V	200A

OEM Part



Contactor Kit for SW181
A.A.21.0681G1

LT#	Voltage	Current
A.A.01.0624G1	24V	200A
A.A.01.0636G1	36V	200A
A.A.01.0648G1	48V	200A
A.A.01.0680G1	80V	200A

SW200 Series Contactor

Original Albright



LT#	Model Number	Voltage	Current
A.A.01.0512A1	SW200-51	12V	400A
A.A.01.0524A1	SW200N-336	24V	400A
A.A.01.0536A1	SW200-230	36V	400A
A.A.01.0548A1	SW200-1	48V	400A
A.A.01.0548A2	SW200-262	48V	400A
A.A.01.0580A1	SW200-802	80V	400A
A.A.01.0580A2	SW200-583	80V	400A

OEM Part



Contactor Kit for SW200
A.A.21.0520G1

LT#	Voltage	Current
A.A.01.0512G1	12V	400A
A.A.01.0524G1	24V	400A
A.A.01.0536G1	36V	400A
A.A.01.0548G1	48V	400A
A.A.01.0548G2	48V	400A
A.A.01.0580G1	80V	400A
A.A.01.0580G2	80V	400A

SU280 Series Contactor (Original Albright)



(OEM Part)
Contactor Kit for SU280
A.A.21.0781G1

LT#	Voltage	Current
A.A.01.1824A1	24V	350A
A.A.01.1836A1	36V	350A
A.A.01.1848A2	48V	350A
A.A.01.1880A2	80V	350A

SW82 Series Contactor

Original Albright



LT#	Model Number	Voltage	Current
A.A.01.0724A1	SW82-3/90P	24V	100A
A.A.01.0736A2	SW82-6	36V	100A
A.A.01.0748A1	SW82-157P	48V	100A
A.A.01.0760A1	SW82-307P	60V	100A

OEM Part



LT#	Description	Voltage	Current
A.A.01.0724G1	SW82	24V	100A
A.A.01.0736G1	SW82	36V	100A
A.A.01.0748G1	SW82	48V	100A

SW84 Series Contactor (OEM Part)



LT#	Description	Voltage	Current
A.A.01.2312G1	SW84	12V	100A
A.A.01.2324G1	SW84	24V	100A
A.A.01.2336G1	SW84	36V	100A
A.A.01.2348G1	SW84	48V	100A

SW182 Series Contactor (OEM Part)




LT#	Description	Voltage	Current
A.A.01.1524G1	SW182	24V	200A
A.A.01.1536G1	SW182	36V	200A
A.A.01.1548G2	SW182	48V	200A

SW190 Series Contactor (OEM Part)



LT#	Description	Voltage	Current
A.A.01.1024G1	SW190	24V	200A
A.A.01.1048G1	SW190	48V	200A
A.A.01.1048G2	SW190	48V	200A

SW202 Series Contactor (OEM Part)




LT#	Description	Voltage	Current
A.A.01.0912G1	SW202	12V	400A
A.A.01.0924G2	SW202	24V	400A
A.A.01.0948G1	SW202	48V	400A
A.A.01.0972G1	SW202	72V	400A
A.A.01.0980G1	SW202	80V	400A

SW822 Series Contactor (OEM Part)



LT#	Description	Voltage	Current
A.A.01.1612G1	SW822	12V	100A
A.A.01.1624G1	SW822	24V	100A
A.A.01.1636G1	SW822	36V	100A
A.A.01.1648G1	SW822	48V	100A
A.A.01.1672G1	SW822	72V	100A


GE100 Series Contactor (OEM Part)



Contactor Kit for GE100
A.A.22.0510G1

LT#	Voltage	Current
A.A.02.0524G1	24V	100A
A.A.02.0548G1	48V	100A
A.A.02.0580G1	80V	100A

GE150 Series Contactor (OEM Part)



Contactor Kit for GE150
A.A.22.0415G1

LT#	Voltage	Current
A.A.02.0424G1	24V	150A
A.A.02.0448G1	48V	150A

GE300 Series Contactor

Original GE



LT#	Model Number	Voltage	Current
A.A.02.0324A1	IC4482CTTA300AH124XN	24V	300A
A.A.02.0348A1	IC4482CTTA300AH248XN	48V	300A
A.A.02.0380A1	IC4482CTTA300AH76XN	72/80V	300A

GE300 Series Contactor



OEM Part



Contactor Kit for GE300
A.A.22.0330G1

LT#	Voltage	Current
A.A.02.0324G1	24V	300A
A.A.02.0336G1	36V	300A
A.A.02.0348G1	48V	300A
A.A.02.0348G2	48V	300A
A.A.02.0372G1	72V	300A
A.A.02.0380G1	80V	300A

GE154 Series Contactor (OEM Part)



Contactor Kit for GE154
A.A.22.0215G1

LT#	Voltage	Current
A.A.02.0224G1	24V	150A
A.A.02.0248G1	48V	150A
A.A.02.0280G1	80V	150A

GE304 Series Contactor

Original GE



LT#	Model Number	Voltage	Current
A.A.02.0124A1	IC4482CTTA304FR124XN	24V	300A
A.A.02.0148A1	IC4482CTTA304FR248XN	48V	300A

OEM Part



Contactor Kit for GE304
A.A.22.0130G1

LT#	Voltage	Current
A.A.02.0124G1	24V	300A
A.A.02.0136G1	36V	300A
A.A.02.0148G1	48V	300A
A.A.02.0160G1	60V	300A
A.A.02.0172G1	72V	300A
A.A.02.0180G1	80V	300A

ZJ50 Series Contactor (OEM Part)



LT#	Description	Voltage	Current
A.A.03.0512G1	ZJ50	12V	50A
A.A.03.0524G1	ZJ50	24V	50A
A.A.03.0536G1	ZJ50	36V	50A
A.A.03.0548G1	ZJ50	48V	50A
A.A.03.0572G1	ZJ50	72V	50A

ZJ100 Series Contactor (OEM Part)



LT#	Description	Voltage	Current
A.A.03.1012G1	ZJ100	12V	100A
A.A.03.1024G1	ZJ100	24V	100A
A.A.03.1036G1	ZJ100	36V	100A
A.A.03.1048G1	ZJ100	48V	100A
A.A.03.1060G1	ZJ100	60V	100A
A.A.03.1072G1	ZJ100	72V	100A
A.A.03.1080G1	ZJ100	80V	100A

ZJ200 Series Contactor (OEM Part)



LT#	Description	Voltage	Current
A.A.03.2012G1	ZJ200	12V	200A
A.A.03.2024G1	ZJ200	24V	200A
A.A.03.2036G1	ZJ200	36V	200A
A.A.03.2048G1	ZJ200	48V	200A
A.A.03.2060G1	ZJ200	60V	200A
A.A.03.2072G1	ZJ200	72V	200A
A.A.03.2080G1	ZJ200	80V	200A

ZJ400 Series Contactor (OEM Part)



LT#	Description	Voltage	Current
A.A.03.4012G1	ZJ400	12V	400A
A.A.03.4024G1	ZJ400	24V	400A
A.A.03.4036G1	ZJ400	36V	400A
A.A.03.4048G1	ZJ400	48V	400A
A.A.03.4060G1	ZJ400	60V	400A
A.A.03.4072G1	ZJ400	72V	400A
A.A.03.4080G1	ZJ400	80V	400A

Linde Contactor

Original Linde



Contactor Kit for Linde LL06-L180A

LT#	Model Number	Voltage	Current
LL05-L032A	DC182B-726L	24V	200A
LL05-L034A	DC182B-733	48V	200A
LL05-L038A	DC182B-698	80V	200A

OEM Part



Contactor Kit for Linde LL06-L180G

LT#	Voltage	Current
LL05-L032G	24V	200A
LL05-L034G	48V	200A

Linde Contactor

Original Linde



LT#	Model Number	Voltage	Current
LL05-L214A	SW215-17	48V	400A
LL05-L218A	SW215-16	80V	400A

OEM Part



Contactor Kit for Linde LL06-L210G

LT#	Voltage	Current
LL05-L214G	48V	400A
LL05-L218G	80V	400A

Linde Contactor (OEM Part)



LT#	Model Number	Voltage	Current
LL05-L062G	SW60	24V	80A
LL05-L082G	ZJWT100L	24V	100A
LL05-L083G	SW80P	24V	100A
LL05-L084G	SW80P	48V	100A
LL05-L085G	SW80P	48V	100A
LL05-L064G	ZJWP80A	48V	80A
B.B.01.1624G2	ZJWP80DE	24V	80A

Linde Contactor (Original)
24V 150A




LT#:LL05-L102A
C100/200

Linde Contactor (Original)
48V 125A



LT#:LL05-L084A
SW80-1723P

Linde Contactor (Original)
48V 250A



LT#:LL05-L314A
0009703503


Nichiyu Contactor



Contactor Kit for Nichiyu
A.A.26.0110G1

LT#	Model Number	Voltage
LL05-N102G	ZJN100A/MS34-20	24V
LL05-N104G	ZJN100A/MS34-20	48V


Nichiyu Contactor



Contactor Kit for Nichiyu
A.A.26.1110G1

LT#	Model Number	Voltage
LL05-N114G	ZJN100A-2T/MS34-23	48V

Nichiyu Contactor



Contactor Kit for Nichiyu
A.A.26.0220G1

LT#	Model Number	Voltage
LL05-N203G	ZJN200A/36V	36V
LL05-N204G	ZJN200A/MS44-20	48V


Nichiyu Contactor



Contactor Kit for Nichiyu
A.A.26.1220G1

LT#	Model Number	Voltage
LL05-N212G	ZJN200A-2T/MS44-23	24V
LL05-N214G	ZJN200A-2T/MS44-23	48V

Nichiyu Contactor



LT#	Model Number	Voltage
LL05-N302A	HR-22P4A/08-3956	48V

Lift Contactor



LT#	Model Number	Voltage
B.B.02.0112G1	W800801-1	12V
B.B.02.0124G1	W800801-2	24V
B.B.02.0136G1	W800801-2	36V

Lift Contactor



LT#	Model Number	Voltage
B.B.02.0212G1	QCC15-200A/10(DY)	12V
B.B.02.0224G1	QCC15-200A/10(DY)	24V

Lift Contactor



LT#	Model Number	Voltage
B.B.02.0212G2	QCC15-200A/10	12V
B.B.02.0224G2	QCC15-200A/10	24V

Lift Contactor



LT#	Model Number	Voltage
B.B.02.0224G3	QCC15-200A	24V
B.B.02.0248G1	QCC15-200A	48V

Lift Contactor (Mahle)



LT#	Model Number	Voltage
B.B.02.0312A1	ARD1379	12V
B.B.02.0324A1	ARD1384	24V

Lift Contactor (TBT)



LT#	Model Number	Voltage
B.B.02.0512A1	684-1261-212-17	12V
B.B.02.0512A2	684-1261-232-02	12V
B.B.02.0524A1	684-2461-212-17	24V

Lift Contactor



LT#	Model Number	Voltage
B.B.02.0612G1	DF12(200A)	12V
B.B.02.0624G1	DF24(200A)	24V

Lift Contactor
24V



LT#:B.B.02.0524A3

762-2401-211-58
Used for EP/Xilin/Jiali/Noblelift

Lift Contactor
48V



LT#:B.B.02.0548G2

ZDJ 4801
Used for EP

Lift Contactor (Ametek)
36V



LT#:LL05-D013A

HB1WM3603B
Used for Doosan

Toyota Contactor
36V



LT#:LL05-T013A

24420-13300-71
Used for Toyota

Toyota Contactor
48V



LT#:LL05-T041G

24750-13700-71
Used for Toyota

Lift Contactor (Taike)
48V



LT#:A.A.09.0248G1

JQX200-48ND

Lift Contactor (Taike)
72V



LT#:A.A.09.0272G1

JQX200-72ND

Lift Contactor (Schaltbau)
12V



LT#:B.B.01.1312A1

C110B/300 12RX T002
Used for Byd

Lift Contactor (Schaltbau)
24V



LT#:B.B.01.1324A1

C100/120 24RX 01
Used for Noblelift

Lift Contactor
24V



LT#:B.B.01.1524G1

ZJWP100L
Used for EP

Lift Contactor
48V



LT#:B.B.01.1648G2

ZJWP80DE



LT#:B.B.01.1672G1

ZJWP80DE
Used for Liftstar

Power Steering Actuator



LT#:LS25-C001G

Used for Tcm/Nichiyu

Power Steering Actuator Assy
48V 350W



LT#:LS25-C002G

Used for Tcm/Nichiyu

Power Steering Actuator Assy
48V 550W



LT#:LS25-C003G

Used for Tcm/Nichiyu

Power Steering Actuator Assy
72V 550W



LT#:LS25-C004G

Used for Tcm/Nichiyu

Ball Screw Rod



LT#:LS25-C102G

Used for Tcm/Nichiyu

Ball Screw Rod



LT#:LS25-C103G

Used for Tcm/Nichiyu

Boot



LT#:LS25-C104G

Used for Tcm/Nichiyu

Ball Screw Rod Kit



LT#:LS25-C105G

Used for Tcm/Nichiyu

Triple Board



LT#:LS25-C107G

Used for Tcm/Nichiyu

Triple Board



LT#:LS25-C108G

Used for Tcm/Nichiyu

Steering Screw Connecting Rod



LT#:LS25-C109G

Used for Tcm/Nichiyu

Ball Screw Rod



LT#:LS25-N101G

Used for Nissan